## .en.-CZUR-ET16-Document-Scanner

Autor:

Data de publicació: 07-05-2020

CZUR ET16 Plus Advanced Book&Document Scanner, 2nd Gen Auto-Flatten & Deskew Tech, 16MP Sony Camera, Capture A3, 186 languages OCR, Convert to PDF/Searchable PDF/Word/TIFF/Excel, Run On Windows&Mac OS

Czur ET 16 Scanner Software Instruction by DH Innovation Czur UK - YouTube

MiniScan Czurtek V-Master 1000 Book Scanner with Duel Lens, V-Shaped Book Cradle - YouTube

Product description

ET16 PLUS

Czur ET16 automatically identify and flatten the curve distortion of books, using a Lagrange transformation. Unlike any other traditional scanners, CZUR ET16 revolutionizes your scanning experience by bringing simple, intelligent and fast scanning performance.

All books, magazines, contracts and any paper documents within size A3 can be scanned directly without cutting or damaging in the speed of 1.5s/page (40-60pages/min).

The CZUR ET16 is also capable of scanning physical objects such as sculptures.

All of your scanned documents can be converted to editable Word/PDF/TIFF or JPG.

A replicated digital document will be created also automatically erasing the fingers that hold the book in place.

All documents you scanned can be uploaded to CZUR Cloud via Wi-Fi.

Easily synchronize your files to any devices you wanted, giving you more flexibility to manage your scanned data

Specification Modal: ET16+ Color: Black Scan speed: <1.5S

Maximum format: A3 Sensor: HD CMOS

Camera pixel: 16Mpix

Optical Resolution: 4608 x 3456

Light source: Natural light + Auxiliary light

Focus mode: Auto focus

Preview resolution: HDMI preview 1920\*1080P Video frame rate: HDMI 1080P 30 frame/s

Video output format: Mjpg?YUV Image format: JPG, PDF, TIFF Color digits: 24-bit color TFT screen: 2.4inches, 4:3 screen

Storage: Nand Flash 1G

Power Supply: External adapter, input 100-240V, 50/60Hz, output 9V/2A

Package 1 x Czur ET16+ Scanner, 1 x Scan pad, 1 x Adapter, 2 x Finger cot, 1 x Foot switch, 1 x Hand switch

Connection
a) Take out the scanner and accessories from the package, then connect the DC power adapter, USB cable and scan button in turn;
b) Place the black soft pad under the scanner's lens, adjust the pad to ensure that the two corners are aligned with the base. Make sure the pad can cover the entire display, and no other things exposed except the document to be scanned. Check the LCD on the head portion to see if the black soft pad covers the entire screen and ensure that the desk surface or random edges are not included within the scan? Tips: All the scanning work must be done on the soft texture pad.?
c) Please turn on the LED light when scanning. There are two brightness levels for the LED light. Please adjust light level at your needs.
Download product software
Please download the software installation package on official website?https://www.czur.com/support/et16plus#software
Select the color mode
Please select the color mode on the right side of the preview interface. There are Color, Patterns, Stamps, Grayscale and B&W 5 color modes in total.

Select the processing method			
Please select the processing method on the Page]?Manual Selection and No processing	e right side of the prog.	eview interface. There ar	re [Flat Single Page]?[Facing
Select the scan mode			
Foot Pedal Hand Button	Keyboard Plate	Scan button in software	<u>.</u>
Toot Four Hand Batton	Noybourd Flate	Court button in sortware	•
Export scan results			
a) Select 'All' images on the file list;			

b) Export all the images to PDF, Searchable PDF or OCR(word) file.
c) Edit the scan results in Batch.
Select 'All' images on the file list;
You can change color mode, choose rotate, crop, standardize, or carry out various types of batch processing for multiple images.
multiple images.
How to Scan books?
How to scan curved books?
a) Toronto di constanti la contrata di Francia a Propositi di Contrata di Cont
a) Turn on the scanner, then select [Facing Pages] processing mode.
b) Keep the bound document open, you may press the blanks on both sides of the pages. Please wear the finger cots
when pressing the document. Foot pedal are more convenient for scanning bound documents.
c) The software will automatically flatten curved, finger removal, perform deviation correction, edge trimming and
quality adjusting of the pages.

d) Please close the preview window for scanning results.
How to scan reflective books?
When you scan reflective materials such as magazines or glossy books. Please turn on the side lights and turn off the built-in LED light to start scan.
Exceptional problems
When you power on the scanner, it does not respond
a) Make sure the power adapter is powered, you can see the power indicator and scanner display are on.
b) If it still does not work, please contact our customer service for support.
Software prompted "Detecting devices"
a) Check the scanner's drive (CZUR) was installed successfully (In imaging devices or Camera).
b) If the scanner driver is installed successfully, you can
I. Check software version is latest verison or not.
II.Turn on the scanner and connect it with PC,check the firmware version can be recognized or not.

III. Restart your PC and shut down the antivirus software first (Make sure the antivirus in background processes also ended).
Then re-install software and try again.
IV. Change another USB port and try again (including the USB port which connect keyboard and mouse).
V. Enter Visual Presenter mode, click "Display" button then check if the image can appear or not.
VI. Make sure in Windows Privacy "camera privacy settings","Let apps use my camera" is on! Website below for you reference.
https://www.thewindowsclub.com/privacy-settings-windows-10
VII. Make sure PC's camera can work properly.
VIII.Change another PC and try again.
c) If the above methods doesn't help, please send software version of this scanner to
customer service for support.
After [Facing Pages] scanning, the finger removal failed
a) Make sure to wear the finger cots when you scanning.
b) Make sure the left thumb wears left finger cots, the right thumb wears the right finger cots.
c) Make sure the finger cots pressed in the middle of the edge (as shown), neither upside nor downside.
d) Send the wrong image to the customer service.

Glossary
What is Stamps?
The Stamps is a proprietary word for the CZUR Scanner, which is a color processing mode that converts background color of the image to white and optimizes the colors of stamp markings. Suitable for stamped official documents printed on white paper.
What is Patterns?
The Patterns is a proprietary word for the CZUR Scanner, which is a color processing mode that maximizes watermarks and other markings with optimization of image color. Suitable for documents that bear watermarks or stamps. This model is suitable for documents with special watermarks and shading, such as ID cards, passports and other materials. The scanning results keep the effect of the document.
What is [Flat Single Page]?
[Flat Single Page] is an CZUR scanner proprietary word, which is a paper processing mode. This mode is suitable for flat and non-curved (without finger pressing, without flattening and paging) material scanning, such as business cards, invoices, courier orders, book covers and single page documents. After scanning, the software will automatically perform deviation correction, edge trimming and quality adjustment of the pages.
What is [Facing Pages]?
[Facing Pages] is CZUR scanner proprietary word, which is a paper processing mode. This mode applies to the scanning of bound documents which have curved pages after opening including books, files etc. After scanning, the software will automatically flatten curve, remove finger, perform deviation correction, edge trimming and quality adjustment of the pages.