## Audio output on an Android

Start playing some music using a Bluetooth device.

•
Autor: Data de publicació: 28-02-2024
REVIEWS TECH
How to change the audio output on an Android without disconnecting your headphones or speakers
Written by Dave Johnson
Mar 6, 2021, 5:05 AM CET
Share
Save
You can change the audio output on Android 11 in a few simple steps for easier listening across devices.damircudic/Getty Images
You can change the audio output on Android 11 by enabling Developer Mode on your phone. Once enabled, you can switch devices by pulling down the media player's notification and expanding the media controls.
If your phone is running Android 11 or later and your audio app supports it, you can now easily change your audio output destination with just a tap or two without the need to disconnect and reconnect playback devices. This lets you easily switch between Bluetooth earbuds and Bluetooth speaker, for example, in the middle of playing music on Spotify.
How to change the audio output on Android 11 Before you can use the feature, you probably need to enable it, which you can find in Android's Developer Options. Our

Swipe down from the top of the screen to see notifications. Swipe down a second time. Tap the small button at the top right of the player notification tile.

Tap the button at the top right of the media player notification banner. Dave Johnson/Insider

In the media player pop-up, you'll see a list of connected audio devices. Tap the one you want to switch to.

How to enable audio switching on Android 11

Start the Settings app and tap "About Phone."

Find the entry for "Build number" and tap it seven times. After three taps you should see a pop-up that tells you you're four taps away from being a developer.

Keep tapping until your phone asks you to enter your PIN. Enter it, and Developer Mode is now enabled.

Tap your build number seven times to enable Developer Mode. Dave Johnson/Insider

Tap the back arrow to go to the main page in Settings.

Tap "System" and then tap "Advanced."

Scroll down to the Media section, then turn on "Media resumption" by swiping the button to the right.

You can now switch among various connected devices. Dave Johnson/Insider