
RF-Remote - 433MHz - DC 12V 4CH Wireless Receiver - HS826

Autor:

Data de publicació: 05-10-2017

AK-RK04S-12 multifunction, learning and 4-channel remote switch controller

Description:

? Learning code wireless remote control switch (receiver), the way of working of output control can be changed as desired (3 modes jumper selectable), easy to pair-match (memorize) up to 16 remote transmitters.

? The AK-RK04S-12 4 channel wireless remote control switch with 4 Relays. It can make the equipment to switch on/off or reverse as desired. Dimensions are small and has an stable and reliable performance, with high receiving sensitivity-more than -105dBm.

Technical Data:

1. working voltage: DC12V
2. quiescent condition: less than 6 mA
3. working temperature: -40°C to +80°C
4. receiver sensitivity: better than -105dBm
5. working frequency: 315/433MHz
6. switch output voltage: 14VDC or 115VAC
7. max load current: 20A
8. dimensions: 72 mm x 52 mm x 26 mm

Output working mode:

1. Jog --Momentary-- jumper free, JP1 and JP2 not connected.

-Pressing&holding button A switches ON, releasing button A switches OFF, uses one channel switch and 1 button on the remote)

2. Self-lock --Latched-- connect jumper cap on JP1

-Pressing button A one time switches ON, pressing the same button A again switches OFF, uses one channel switch and 1 button on the remote

3. Inter-lock --Toggle-- connect jumper cap on Jp2

-Pressing button A switches ON, pressing button B switches OFF, uses one channel switch and 2 buttons on the remote

Pairing-Learning and Reset-Clear method:

a. Pairing remote: press the PROG button. the indicator switches OFF, release your finger, press any button on the remote control, the indicator flashes 3 times and switches ON, that means pairing was successful.

b. Controller reset/clear: press the PROG button about 8 seconds, meanwhile the indicator remains OFF & then turns ON, this means the information that was kept has been removed successfully.

WARNING: It can pair-learn 16 PCS of 2262 or 1527 wireless chips with different remote codes. Each pairing of any remote after the 16th element, removes the pairing data of the first unit in the pairing list.

Applications:

Auto door, window lifting equipment, entrance access, up and down controller, alarm system, industrial control and security etc.

The receiver module is compatible with chips 2262/2260/1527/2240 etc.. and several other codes of wireless remote control units. So it fulfills the need of using the wireless remote control that one needs to work with.

Receiver is matched to each remote frequency, working together (old receivers were broadband & their working frequency, didn't care).

Package Includes: <http://belchip.by/sitedocs/17863.pdf>

1 x Receiver

4 x transmitters

Caractéristiques :

Vient avec 4 Transmetteur et 1 récepteur.

Le volume est petit et la performance est stable et fiable, la sensibilité de réception élevée, distance de commande à distance jusqu'à 50-100m.

Utilisation de la technique de codage sans fil, commutateur non directionnel, ne pas interférer les uns avec les autres. Avec un couvercle coulissant sur la télécommande, pour protéger les boutons éviter un fonctionnement accidentel non planifié.

Ces télécommandes sont conçues pour contrôler une grande variété de dispositifs électroniques avec un signal sans fil. Extrêmement facile à installer et à utiliser.

Il couvre l'application allant de la télécommande domestique simple au contrôle autonome, comme la porte automatique, la fenêtre, l'équipement de levage, l'accès d'entrée, le contrôleur ascendant et descendant, le contrôle d'alarme industriel et la sécurité etc.

Spécifications :

Fréquence de Fonctionnement : 433MHZ

Tension de fonctionnement : DC 12V

Courant nominal max. : 20A

Sensibilité de réception : -105DB

Mode de fonctionnement : mode Jog, mode inter-verrouillé, mode de verrouillage automatique

Taille du boîtier du récepteur : 7.5 x 5.5 x 2.5cm

Taille : 5.5 x 3 x 1.3cm

Comment programmer :

Appairer la télécommande : Appuyer sur la touche d'apprentissage jusqu'à ce que le voyant s'éteigne. Appuyez sur un bouton de la télécommande, le voyant clignote 3 fois, à ce moment, la télécommande est appairée avec succès.

Réinitialiser : Appuyer sur le bouton d'apprentissage et maintenir enfoncée pendant 6 secondes, le témoin lumineux s'éteint, l'opération est réussie. toute télécommande précédemment couplée a été Supprime.

Le Paquet comprend :

1 x Récepteur d'Apprentissage de Code

4 x Télécommande Émetteur

Item Specifics

Marque

- Sans marque -

Numéro de pièce fabricant

Non applicable