
Stop the home button waking Samsung Galaxy S5

Stop the nome button waking Samsung Galaxy 55						
Autor: Data de publicació: 07-08-2017						
I've only had my Samsung Galaxy S5 for about a week now. I've been mowing the lawn whilst listening to music. Every so often, the music would stutter or skip to the next track. When I took my phone out of my pocket, it was still locked, but awake. And on the lock screen whilst playing music are controls to pause and skip tracks. So I'm guessing that the home button is being pressed by my leg and the controls on the screen are being pressed.						
Is there some way of making it so that the home button does not wake the device, or at least not when it's in my pocket?!						
Perfect answer						
If you rooted your S5 it is pretty simple (and you don't have to install third party apps): 1) use a file manager and go into root -> system -> usr -> keylayout and find the file gpio-keys.kl; 2) Open it with a text editor and find the lines with "WAKE" written in them; 3) Go to the one with "HOME" written in it and just delete this word and all the spaces between the number on the left and "WAKE" on the right; 4) Save the file and you're done;						
If you can't do this in 30seconds thing because your S5 is not rooted then I'd suggest you to root your phone: a new world opens right in front of you;)						
shareimprove this answer						
answered Sep 30 '14 at 8:32						


Leon Guerrero 365212

I don't think you can without installing a custom ROM.
shareimprove this answer
answered May 22 '14 at 22:37
DanielStewart 1266
Unfortunately, I think you're right. I can't find anything online to suggest that it's an option built into the standard



Neil 112
add a comment
up vote 0 down vote
If anyone is searching for a solution here, here's what I did. I use the "SlideLock" app for my lock screen. This way I get iOS style notifications on the lockscreen. In the "Settings" >> "Lockscreen" for SlideLock, there's an option to "Block home button" - prevent unlocking the device using the home button. I activated that, and now that stops accidental activations or turning on of the phone. Hope that helps. :)
shareimprove this answer
answered Aug 31 '14 at 1:19

3ob
This answer would be much more useful if you included a link to the app you're recommending. – ale Aug 31 '14 at 3:5
s it SlideLock Locker that you're recommending? play.google.com/store/apps/details?id=com.slidelock&hl=en – Matty Brown Sep 1 '14 at 15:21



add a comment
up vote -2 down vote
Get a s view case. Not only does it have room cut out for the button, the magnets stop the phone also to unlock
shareimprove this answer
snarelinprove triis answer
answered Nov 16 '14 at 12:47
rob
1
add a comment
add a comment

C.U.N.T.
It is very unlikely that the songs are being skipped because of the on screen buttons. All smart phone screens now a days are capacitive. You need something conductive, like your skin, to touch the screen for the buttons to be activated.
- bobbyalex May 23 '14 at 1:15
1
Hi Bobby. The Samsung Galaxy S5 screen can be operated with gloves (any gloves, not just special capacitive gloved). Is also has a feature called Air View, which allows you to do some things without actually making physical contact with the screen - you just hover your finger about 5mm from it and it somehow detects it's there and reacts. Very clever technology, no doubt. But I just want to stop my phone waking up and doing stuff when it's in my pocket. – Matty Brown May 24 '14 at 14:16
Matty, is air view enabled on your phone? If yes, do you use it? – bobbyalex May 24 '14 at 14:50

@BobbyAlexander No, I have both was curious to see what it was. – M	Air View and extra latty Brown May 24	a Touch Sensitivity turned off. 4 '14 at 21:39	I only looked at	Air View because